





## Model XPT02Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	187269-4	HOUSING SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 15		
002	853L76-6	XPT02 NAME PLATE	1	
003	266130-9	TAPPING SCREW BIND PT 3X16	9	PC.
004	126105-9	SPEED CHANGE LEVER ASSEMBLY	1	PC.
	C10 234232-9	COMPRESSION SPRING 3	2	PC.
005	419041-9	F/R CHANGE LEVER	1	PC.
006	650673-5	SWITCH C3JW-1A	1	PC.
007-1	126341-7	IMPACT ASSEMBLY M	1	PC.
	D10	INC. 18-65		
008	638958-9	SWITCH UNIT	1	PC.
009	638959-7	SWITCH UNIT	1	PC.
010	638899-9	STATOR COMPLETE	1	PC.
	D10	INC. 8,9		
011	619292-6	ROTOR	1	PC.
012	620092-9	LED CIRCUIT	1	PC.
013	643860-3	TERMINAL	1	PC.
014	141268-0	SWITCH PLATE COMPLETE	1	PC.
015	187269-4	HOUSING SET	1	PC.
	C10 263005-3	RUBBER PIN 6	2	PC.
	D10	INC. 1		
018	231951-8	RING SPRING 11	1	PC.
019	267085-1	FLAT WASHER 12	1	PC.
020	233005-7	COMPRESSION SPRING 13	1	PC.
021	324420-7	SLEEVE	1	PC.
022	424485-0	BAMPER	1	PC.
023	135505-2	HAMMER CASE ASS'Y	1	PC.
024	453321-3	CHANGE RING	1	PC.
025	232272-1	LEAF SPRING	1	PC.
026	257809-3	SLEEVE 24	1	PC.
027	961085-0	RETAINING RING WR-15	1	PC.
028	223175-0	CAM A	1	PC.
029	223176-8	CAM B	1	PC.
030	216019-1	STEEL BALL 3	22	PC.
031	267839-6	CUP WASHER	1	PC.
032	346560-1	HAMMER CHANGE PLATE	2	PC.
033	313227-6	HAMMER CHANGE RING	1	PC.
034	234231-1	COMPRESSION SPRING 2	2	PC.
035	453320-5	CHANGE CASE	1	PC.
036	135504-4	GEAR CASE ASS'Y	1	PC.
037	453324-7	PIN GUIDE	2	PC.
038	256537-7	FLAT FILLISTER HD. PIN 1.2-3.5	2	PC.
039	261130-4	NYLON WASHER 15	1	PC.
040	213166-9	O RING 12.5	1	PC.
041	216001-0	STEEL BALL 3.5	2	PC.
042	326126-3	ANVIL M	1	PC.
043	234233-7	COMPRESSION SPRING 5	1	PC.
044	216011-7	STEEL BALL 5.6	1	PC.

045	256272-7	PIN 2.5	6 PC.
046	326123-9	HAMMER	1 PC.
047	234234-5	COMPRESSION SPRING 22	1 PC.
048	331977-1	CHANGE SLEEVE	1 PC.
049	216019-1	STEEL BALL 3	6 PC.
050	326124-7	OUTER HAMMER	1 PC.
051	216019-1	STEEL BALL 3	34 PC.
052	267453-8	FLAT WASHER 14	1 PC.
053	216011-7	STEEL BALL 5.6	2 PC.
054-1	142037-2	SPINDLE COMPLETE	1 PC.
055	211379-6	BALL BEARING 6805LLB	1 PC.
056	453325-5	BEARING CASE	1 PC.
057-1	227319-4	SPUR GEAR 41	1 PC.
058-1	227320-9	SPUR GEAR 14B	5 PC.
059	268266-0	FLAT FILLISTER HD. PIN 1.2	4 PC.
060	453323-9	CHANGE LEVER	1 PC.
061	227287-1	INTERNAL GEAR 41	1 PC.
062	141251-7	SPUR GEAR 14A COMPLETE	1 PC.
063	227284-7	SPUR GEAR 21	3 PC.
064	135506-0	MOTOR BRACKET ASS'Y	1 PC.
065	211022-7	BALL BEARING 607ZZ	1 PC.
A01	251314-2	+ SCREW M4X12	1 PC.
A02-1	346449-3	HOOK	1 PC.
E01	813H98-4	CAUTION LABEL	1