



ES

SPAIN

Diagram / Parts List

TD127D

CORDLESS IMPACT DRIVER



This exploded view diagram illustrates the assembly of a Traxxas TQi 2.4GHz radio transmitter. The components are numbered 1 through 32, showing their relative positions and how they fit together. The diagram includes the main body (1), the antenna (3), the battery pack (5), the receiver (6), the battery cover (7), the antenna switch (8), the antenna base (9), the antenna nut (10), the antenna cap (11), the antenna screw (12), the antenna ring (13), the antenna washer (14), the antenna pin (15), the antenna bracket (16), the antenna wheel (17), the antenna disc (18), the antenna ring (19), the antenna nut (20), the antenna washer (21), the antenna pin (22), the antenna cap (23), the antenna screw (24), the antenna nut (25), and the antenna washer (26). The transmitter is shown in its assembled state at the bottom left, with the Traxxas logo visible on the front panel.

ES**SPAIN****TD127D / CORDLESS IMPACT DRIVER**

| Item | Sub | Parts No. | Parts Description | Qty | I/C | E/C No. | Close No. | Remark |
|--------|-----|-----------|------------------------|-----|-----|---------|-----------|--------|
| 001 | | 187420-6 | HOUSING SET | 1 | | | | |
| | C10 | 252126-6 | HEX. LOCK NUT M4-7 | 2 | | | | |
| | D10 | | INC. 32 | | | | | |
| 002 | | 266429-2 | TAPPING SCREW 3X16 | 8 | | | | |
| 003 | | 897581-1 | TD127D NAME PLATE | 1 | | | | |
| 005 | | 453055-8 | F/R CHANGE LEVER | 1 | | | | |
| 006A | | 632A32-1 | SWITCH UNIT | 1 | | | B5112 | |
| | C10 | 688165-4 | LINE FILTER | 1 | | | B5112 | |
| 006B | | 632A32-1 | SWITCH UNIT | 1 | | | B5112 | |
| | C10 | 688165-4 | LINE FILTER | 1 | | | B5112 | |
| 006-1A | | 632J79-9 | SWITCH UNIT | 1 | < | B5112 | | |
| | C10 | 688165-4 | LINE FILTER | 1 | | B5112 | | |
| 006-1B | | 632J79-9 | SWITCH UNIT | 1 | < | B5112 | | |
| | C10 | 688165-4 | LINE FILTER | 1 | | B5112 | | |
| 006-1C | | 632J79-9 | SWITCH UNIT | 1 | | | | |
| | C10 | 688165-4 | LINE FILTER | 1 | | | | |
| 007 | | 643862-9 | TERMINAL | 1 | | | | |
| 008 | | 231951-8 | RING SPRING 11 | 1 | | | | |
| 009 | | 267085-1 | FLAT WASHER 12 | 1 | | | | |
| 010 | | 233005-7 | COMPRESSION SPRING 13 | 1 | | | | |
| 011 | | 324420-7 | SLEEVE | 1 | | | | |
| 012 | | 266374-1 | TAPPING SCREW 4X25 | 4 | | | | |
| 013 | | 141585-8 | HAMMER CASE COMPLETE | 1 | | | | |
| 014 | | 261151-6 | NYLON WASHER 19 | 1 | | | | |
| 015A | | 216001-0 | STEEL BALL 3.5 | 2 | | | A4806 | |
| 015B | | 216001-0 | STEEL BALL 3.5 | 2 | | | A4806 | |
| 015-1A | | 216040-0 | STEEL BALL 3.5 | 2 | O | A4806 | | |
| 015-1B | | 216040-0 | STEEL BALL 3.5 | 2 | O | A4806 | | |
| 015-1C | | 216040-0 | STEEL BALL 3.5 | 2 | | | | |
| 016 | | 326188-1 | ANVIL M | 1 | | | | |
| 017 | | 326110-8 | HAMMER | 1 | | | | |
| 018A | | 216001-0 | STEEL BALL 3.5 | 24 | | | A4806 | |
| 018B | | 216001-0 | STEEL BALL 3.5 | 24 | | | A4806 | |
| 018-1A | | 216040-0 | STEEL BALL 3.5 | 24 | O | A4806 | | |
| 018-1B | | 216040-0 | STEEL BALL 3.5 | 24 | O | A4806 | | |
| 018-1C | | 216040-0 | STEEL BALL 3.5 | 24 | | | | |
| 019 | | 267175-0 | FLAT WASHER 24 | 1 | | | | |
| 020 | | 233430-2 | COMPRESSION SPRING 24 | 1 | | | | |
| 021 | | 267766-7 | CUP WASHER 14 | 1 | | | | |
| 022A | | 216011-7 | STEEL BALL 5.6 | 2 | | | A4806 | |
| 022B | | 216011-7 | STEEL BALL 5.6 | 2 | | | A4806 | |
| 022-1A | | 216041-8 | STEEL BALL 5.6 | 2 | O | A4806 | | |
| 022-1B | | 216041-8 | STEEL BALL 5.6 | 2 | O | A4806 | | |
| 022-1C | | 216041-8 | STEEL BALL 5.6 | 2 | | | | |
| 023A | | 226336-1 | SPUR GEAR 22 | 2 | | | B3583 | |
| 023B | | 226336-1 | SPUR GEAR 22 | 2 | | | B3583 | |
| 023-1A | | 227362-3 | SPUR GEAR 22 | 2 | < | B3583 | C5426 | |
| 023-1B | | 227362-3 | SPUR GEAR 22 | 2 | < | B3583 | C5426 | |
| 023-2A | | 227362-3 | SPUR GEAR 22 | 2 | O | C5426 | | |
| 023-2B | | 227362-3 | SPUR GEAR 22 | 2 | O | C5426 | | |
| 023-2C | | 227362-3 | SPUR GEAR 22 | 2 | | | | |
| 024 | | 326109-3 | SPINDLE | 1 | | | | |
| 025 | | 256253-1 | PIN 5 | 2 | | | | |
| 026 | | 267212-0 | FLAT WASHER 12 | 1 | | | | |
| 027 | | 227279-0 | INTERNAL GEAR 51 | 1 | | | | |
| 028 | | 210107-6 | BALL BEARING 6001ZZ | 1 | | | | |
| 029 | | 453056-6 | INTERNAL GEAR CASE | 1 | | | | |
| 030 | | 629969-5 | DC MOTOR | 1 | | | | |
| 032 | | 187420-6 | HOUSING SET | 1 | | | | |
| | C10 | 252126-6 | HEX. LOCK NUT M4-7 | 2 | | | | |
| | D10 | | INC. 1 | | | | | |
| A01B | | 452652-7 | BATTERY COVER | 1 | | | | |
| A01C | | 452652-7 | BATTERY COVER | 1 | | | | |
| A02B | | ***DC18WA | DC18WA BATTERY CHARGER | 1 | | | | |
| A02C | | ***DC18WB | DC18WB BATTERY CHARGER | 1 | | | | |

A:TD127DZ(N)
B:TD127DWE(H)
C:TD127D002(H)

Interchange
O : Yes
X : No
< : the new part can be substituted for the current.
> : the current part can be substituted for the new.
S : Interchangeable as a set.

SPAIN

[illegible]

Interchange
O : Yes
X : No
< : the new part can be substituted for the current.
> : the current part can be substituted for the new.
S : Interchangeable as a set.